


## 7. Repair Part List

### 7.1. Up to 3 tonnes



Exclusive for 2 1/2 & 3 tonnes

| Fig. # | Part # | Part Name                | Parts per Hoist | Capacity (tonnes) |               |               |               |
|--------|--------|--------------------------|-----------------|-------------------|---------------|---------------|---------------|
|        |        |                          |                 | 3/4               | 1 1/2         | 2 1/2         | 3             |
| 1      | 1001   | Top Hook Set             | 1               | L5BC008-1001      | L5BC015-1001  | L5BA025-1001  | L5BC030-1001  |
| 2      | 1071   | Latch Assembly           | 1               | L5BA008-1071      | L5BA016-1071  | L5BA025-1071  | L5BA032-1071  |
| 3      | 163    | Top Pin                  | 1               | L5BA008-9163      | L5BA016-9163  | L5BA025-9163  | L5BA032-9163  |
| 4      | 1021   | Bottom Hook Set          | 1               | L5BC008-1021      | L5BC015-1021  | L5BA025-1021  | L5BC030-1021  |
| 5      | 1071   | Latch Assembly           | 1               | L5BA008-1071      | L5BA016-1071  | L5BA025-1071  | L5BA032-1071  |
| 7      | 41     | Chain Pin                | 1               | L4BA008-9041      | C3BA015-9041  | L5BA025-9041  | L4BH030-9041  |
| 8      | 49     | Slotted Nut              | 1               | C3BA005-9049      | C3BA010-9049  | C3BA020-9049  |               |
| 9      | 96     | Split Pin                | 1               | J1PW01-016010     | J1PW01-020012 | J1PW01-020014 |               |
| 10     | 5101   | Frame A Assembly         | 1               | L5BA008-5101      | L5BA016-5101  | L5BA025-5101  | L5BA032-5101  |
| 11     | 806    | Nameplate F              | 1               |                   | C3BA005-9806  |               |               |
| 12     | 102    | Frame B                  | 1               | L5BA008-9102      | L5BA016-9102  | L5BA025-9102  | L5BA032-9102  |
| 13     | 5103   | Gear Case Assembly       | 1               | L5BA008-5103      | L5BA016-5103  | L5BA025-5103  | L5BA032-5103  |
| 14     | 181    | Domed Cap Nut            | 4               |                   | J1ND002-30080 |               |               |
| 15     | 182    | Spring Lock Washer       | 4               |                   | J1WS012-20080 |               |               |
| 16     | 111    | Pinion                   | 1               | L5BA008-9111      | L5BA016-9111  | L5BA025-9111  | L5BA032-9111  |
| 17     | 112    | Gear #2                  | 2               | L5BA008-9112      | L5BA016-9112  | L5BA025-9112  | L5BA032-9112  |
| 18     | 114    | Load Gear                | 1               |                   |               | L5BA025-9114  | L5BA032-9114  |
| 19     | 116    | Load Sheave              | 1               | L5BA008-9116      | L5BA016-9116  | L5BA025-9116  | L5BA032-9116  |
| 20     | 161    | Chain Guide              | 2               | L5BA008-9161      | L5BA016-9161  | L5BA025-9161  | L5BA032-9161  |
| 21     | 162    | Stripper                 | 1               | L5BA008-9162      | L5BA016-9162  | L5BA025-9162  | L5BA032-9162  |
| 22     | 155    | Pawl                     | 2               | L4BA008-9155      |               | L5BA025-9155  | L4BA030-9155  |
| 23     | 158    | Pawl Spring              | 2               | L5BA008-9158      | L5BA016-9158  | L5BA025-9158  | L5BA032-9158  |
| 24     | 188    | Snap Ring                | 2               |                   | J1SS000-00009 |               | J1SS000-00011 |
| 25     | 153    | Friction Disc            | 1               |                   | L5BA008-9153  |               | L5BA032-9153  |
| 26     | 151    | Friction Plate           | 2               |                   | L5BA025-9151  |               | L5BA063-9151  |
| 27     | 152    | Ratchet Disc             | 1               |                   | L4BA008-9152  |               | L4BA015-9152  |
| 28     | 154    | Bushing                  | 1               |                   | L4BA008-9154  |               | L4BA015-9154  |
| 29     | 5214   | Brake Cover Assembly     | 1               | L5BA008-5214      | L5BA016-5214  | L5BA025-5214  | L5BA032-5214  |
| 30     | 281    | Flange Nut               | 2               |                   | J1NF002-10060 |               | J1NE002-10080 |
| 31     | 184    | Domed Cap Nut            | 4               |                   | J1ND002-30080 |               |               |
| 32     | 185    | Spring Lock Washer       | 4               |                   | J1WS012-20080 |               |               |
| 33     | 160    | Female Thread            | 1               |                   | L5BA008-9160  |               | L5BA032-9160  |
| 34     | 218    | Select Pawl              | 1               |                   | L4BA008-9218  |               | L4BA015-9218  |
| 35     | 222    | Spring Shaft             | 1               |                   | L2BA008-9221  |               | L3BA015-9222  |
| 36     | 223    | Select-pawl Spring       | 1               |                   | L2BA008-9223  |               | L2BA015-9223  |
| 37     | 6211   | Lever Assembly           | 1               | L5BA008-6211      |               | L5BA016-6211  | L5BA032-6211  |
| 38     | 1231   | Grip                     | 1               | L5BA008-1231      |               | L4BA008-1231  | L4BA015-1231  |
| 39     | 232    | Binding Screws           | 1               |                   | L5BA008-9232  |               | L5BA032-9232  |
| 40     | 800    | Nameplate                | 1               | L5BC008-9800      | L5BC015-9800  | L5BC025-9800  | L5BC030-9800  |
| 42     | 221    | Hex Cap Screw            | 1               |                   | L4BA008-9221  |               | L4BA015-9221  |
| 43     | 207    | Brake Spring             | 1               |                   | L4BA008-9207  |               | L4BA015-9207  |
| 44     | 203    | Cam Guide                | 1               |                   | L5BA008-9203  |               | L4BA015-9203  |
| 45     | 201    | Free Chain Knob          | 1               |                   | L4BA008-9201  |               | L4BA015-9201  |
| 46     | 810    | Nameplate U              | 1               |                   | L5BA008-9810  |               |               |
| 47     | 205    | Free Chain Spring        | 1               |                   | L4BA008-9205  |               | L4BA015-9205  |
| 48     | 208    | Spring Holder            | 1               |                   | L5BA008-9208  |               | L5BA032-9208  |
| 49     | 183    | Slotted Nut              | 1               |                   | C3BA020-9049  |               |               |
| 50     | 187    | Split Pin                | 1               |                   | J1PW01-020014 |               |               |
| 52     | 841    | Nickel-plated Load Chain | 1               | KAON056J0000      | KAON071J0000  | KAUN088-0000  | KAON100J0000  |
| 53     | 45     | Chain Stopper Link       | 1               | L5BA008-9045      | L5BA016-9045  | L5BA025-9045  | L5BA032-9045  |
| 54     | 931    | Warning Tag LKA          | 1               |                   | L4BR008-9931  |               |               |
| 55     | 932    | Warning Tag LKB          | 1               |                   | L4BR008-9932  |               |               |